



MOBILE CRANE CONTROL SYSTEM

USER MANUAL

xCrane PRO

TECHNION OY
Linkkikatu 15
21100 Naantali FINLAND

tel. +358 (0)40 191 100
fax +358 (0)2 438 9907

www.technion.fi

Introduction

The xCrane crane control system is used to control different types of cranes. This user manual provides instructions on the safe and efficient use of the xCrane control system that will enable you to maximize productivity.

The safe and effective use of the system ensures the best possible performance and financial return on your machine investment. It is for this reason that we highly recommend reading these instructions carefully before using the system.

This user manual has been drafted and arranged so that its systematic reading will provide a clear understanding of the structure, implementation and use of the control system.

The first section of the manual deals with safety issues related to the control system.

The second section provides an overview of the system architecture and GUI, followed by a detailed presentation of the functions controlled through the GUI.

All the technical specifications, functions and instructions presented in this manual are based on the latest system information available at the time this manual version was drafted. As the system is constantly being developed, the manufacturer reserves the right to make changes to the product without prior notice.

Table of contents

1	System safety.....	7
1.1	General warnings.....	8
2	System architecture	11
3	Navigation.....	13
3.1	Working view	14
3.1.1	Symbol definitions.....	15
3.1.2	Pop-up information	19
3.2	Main page buttons.....	20
3.2.1	Driver selection	20
3.2.2	General speed.....	21
3.2.3	Crane control mode	21
3.2.4	USB settings	22
3.2.5	Menu	22
4	Operating modes	23
4.1	Suspend mode	25
4.2	Stabilizer control	26
4.3	Steering by joysticks mode	27
4.4	Axle lock	28
4.5	Trailer drawbar control	29
4.6	Trailer traction control	30
4.6.1	Differential lock.....	30
4.6.2	Trailer brake.....	30
4.7	Winch control	31
4.8	Floating mode	32
4.9	Radio control mode.....	33
5	System sensors	35
5.1	Outside temperature	36
5.2	Hydraulic oil temperature	37
5.3	Hydraulic oil pressure sensors.....	38
5.4	Load pressure sensor.....	39
5.5	Hydraulic oil filter clogging indicator.....	40
5.6	Hydraulic oil level warning.....	41
6	Operator presence detections features.....	43
6.1	Seat switch mode.....	45
6.2	Door switch mode	46
6.3	Dead man switch safety mode.....	47
6.4	Temporary presence detection mode.....	48
7	Technion Quick trim	49
7.1	Introduction.....	50
7.2	Speed setting process	51
7.3	Examples of Quick Trim.....	53

8	Settings menu	55
8.1	Menu structure	56
8.2	Settings - Crane	57
8.2.1	Max speed	58
8.2.2	Min speed	58
8.2.3	Acceleration ramps	59
8.2.4	Deceleration ramps	59
8.2.5	Speed balance	60
8.2.6	Rotator direction	60
8.2.7	Progression control	61
8.2.8	Slew speed	62
8.2.9	xCrane PLUS	62
8.2.10	xCrane PRO	66
8.3	Adjusting setting values	68
8.4	Data saving	71
8.5	Settings - Joystick	72
8.5.1	Calibration	72
8.5.2	Dead band	73
8.5.3	Filter	74
8.6	Settings - Diagnostic	75
8.6.1	Output	75
8.6.2	Joysticks	75
8.6.3	Sensors	76
8.6.4	Inputs	77
8.6.5	System	77
8.6.6	Software info	78
8.6.7	Fault log	78
8.6.8	Boom position	79
8.7	Settings - System	80
8.7.1	Display settings	80
8.7.2	Copy parameters	81
8.7.3	Factory reset	82
9	USB settings	83
9.1	Read information	85
9.1.1	Backup	85
9.1.2	Configure	85
9.1.3	Default driver	85
9.1.4	Logs	86
9.1.5	Current driver	86
9.2	Write information	87
9.2.1	Restore	87
9.2.2	Configure	87
9.2.3	Default driver	87
9.2.4	Current driver	88
9.3	File transfer information	89
9.3.1	File operation errors	90



1 System safety

1.1 General warnings

Use of the control system involves items that are vital to the safe operation of the machine. Operators must comply with these. Failure to observe these warnings will invalidate your guarantee.

WARNING



Performing maintenance work while the system is powered and the machine is pressurized could cause death or severe injury.

Always switch off the system and depressurize the machine before performing maintenance work.

NOTICE



The xCrane system may only be used and adjusted by trained personnel!

The example values given for the parameters in this manual are guideline values, not optimal values for all machines.

NOTICE



Performing welding work while the connectors of the modules are connected could damage the system.

Always disconnect all the connectors of the modules before performing welding work.



NOTICE



Always use a specific CAN cable with twisted and shielded pair for the CAN bus.


2 System architecture

The system is based on intelligent electronic control units connected via a CAN bus. The main system components are Technion Display Controller, Technion control unit TEC152 and joysticks. The system can also be used without the display.












3 Navigation






3.1 Working view





















In the working view user can change operator, speed for that operator and operating mode. Sensor data is available at the left side of the working view. At the top bar there are some system icons available. Crane manufacturer's system configuration defines, which working view icons are visible.

3.1.1 Symbol definitions

	System date and time
	If this button symbol is visible, there are faults in the system. Fault log can be accessed by pressing the button. If the warning triangle is orange, there are active faults in the system.
 	If the symbol in the button is visible, a USB stick is connected to the system and USB settings can be used.
	Hydraulic oil pressure. Shows the pressure provided by an external sensor. This sensor is an option.
	Outside temperature. Shows the ambient temperature provided by an external sensor. This sensor is an option.
	Hydraulic oil temperature. Shows the oil temperature provided by an external sensor. This sensor is an option.
	Operating voltage. Voltage is read internally in the xCrane module.
	Overload indicator. Measures the hydraulic pressure of the lift boom and uses the pressure to calculate whether the load is a risk to the balance of the machine. The indicator has three states: OK, Warning and Alarm. This sensor is an option.


	<p>Operator's seat indicator and door open/closed indicator.</p> <p>If your crane is equipped with the seat switch safety function, the crane cannot be used if the operator is not in the operator's seat. The seat status can be observed from the display symbol. If the symbol is green, the operator is properly seated in the operator's seat. The symbol is orange when the seat is empty.</p> <p>When the door symbol is visible, the door is open.</p> <p>If the symbol is green and orange, the operator temporal presence mode is active. The green and orange bar on the left side of the icon indicates the remaining pre-defined time.</p> <p>This sensor is an option.</p>
	<p>Float mode active.</p> <p>This symbol is visible if the operator has activated the float mode from the switch. In this mode the crane's lift, jib and swing valves are in floating mode to make sure that the crane is following the trailer.</p>
	<p>The crane is not at the home position and it is not active. The joysticks have been activated to control other functions, such as moving the supporting legs.</p>
	<p>The crane is not at the home position and it is active. The joysticks have been activated to move the crane.</p>
	<p>The crane is at the home position and it is not active.</p>

	The crane is at the home position and it is active.
	The supporting legs are not at the home position and they are not active. The joysticks have been activated to control other functions, such as moving the crane.
	The supporting legs are not at the home position and they are active. The joysticks have been activated to move the supporting legs.
	The supporting legs are at the home position and they are not active.
	The supporting legs are at the home position and they are active.
	There is steering function in the system but it is not activated.
	Steering by joysticks activated.
	Axle Lock is enabled and active if this symbol is visible.
	Trailer traction control activated.
	Differential lock is active. Differential lock function can be used with trailer traction.
	Trailer brake is active.
	Winch control deactivated.
	Winch control activated.


	Trailer drawbar control deactivated.
	The trailer drawbar control is active.
	Oil filter pressure switch indicator.
	Hydraulic oil level low indicator.
	<p>Radio control indicator.</p> <p>The blue symbol indicates high radio signal strength.</p> <p>The yellow symbol indicates low radio signal strength.</p> <p>The red symbol indicates loss of the radio signal.</p> <p>The gray symbol indicates disabled radio control.</p>

3.1.2 Pop-up information

If the CAN connection between TEC152 controller and display is compromised, then following pop-up window will appear.




If fault is detected, it is informed to the user by showing pop-up.




Fault pop-up informs user where the fault is detected (Joystick, valve control or supply).

If system voltage drops below certain level, this situation is informed to the driver with the following pop-up.



If the under-voltage situation happens, all crane movements will stop. System should recover from this situation and working can continue by centering the joysticks. Pop-up can be acknowledged by pressing OK button.

3.2 Main page buttons




At the main working view, a variety of settings can be changed.

1. Menu
2. General speed
3. Driver selection
4. USB settings
5. Crane control mode


If any of the selections (2, 3 or 5) is active, all other menus/selections are disabled.

3.2.1 Driver selection




Driver selection menu can be activated by pressing the button at the right side of the working view. There are six operators in the system, and each operator can have their own set of parameters.

3.2.2 General speed




General speed setting can be activated by pressing the button at the right side of the working view. Value can be set from the slider. Each operator can have their own general speed (more about general speed and Technion Quick Trim can be found from page 49).

3.2.3 Crane control mode




Crane operating mode selection is activated by pressing the button at the right side of the working view. The modes that can be selected depend on the crane manufacturer's system configuration. Active control mode is shown on top of the mode selection button.

3.2.4 USB settings



If the USB is connected and the symbol is active, the USB settings can be accessed by pressing the button at the right side of the working view.

3.2.5 Menu



Enter the menu by pressing the button.



4 Operating modes

The xCrane system has a variety of different operating modes that can be used alongside with the crane. This chapter will have some information about the operating modes and how to use them.

Please contact your dealer about the operating modes


4.1 Suspend mode

If the crane is put to the suspend mode, all the main crane functions are disabled. The color of the crane symbol shows the state of the suspend mode.

	<p>The suspend mode is active.</p>
	<p>The suspend mode is not active.</p>

As a default setting, the suspend mode can be activated from the display. Alternatively, the crane manufacturer can configure an external switch to be used for the suspend mode activation.

Press the crane symbol for two seconds. A pop-up will appear telling that the crane is now suspended. To exit the suspend mode, press the "Yes" button on the pop-up.



4.2 Stabilizer control

Stabilizers can be controlled with joystick Y-axis or using separate thumbwheel or buttons.

If the joystick Y-axis is used, then stabilizer control needs to be enabled with switch.



Stabilizer control state is shown in the working view below the crane image. If the system doesn't have stabilizers configured, the symbol is not shown at all.

4.3 Steering by joysticks mode

The steering mode can be activated by pressing the steering mode switch on the dashboard. Alternatively, xCrane can detect the steering mode automatically from the tractor's control system.

When the steering mode is activated, the functioning of the joystick changes. The rotator movement will be disabled, and the joystick will control the steering valve instead.

Or alternatively steering can be controlled with separate thumbwheel, and then activation switch is not needed, and crane controls are not disabled.

The symbols below indicate the status of the steering mode. When the symbol is blue, the steering by joysticks mode is active. If the symbols are not visible on the display, the steering by joysticks mode is not available.



4.4 Axle lock

The axle lock mode can be activated by pressing the axle lock mode switch on the dashboard. Alternatively, xCrane can detect the axle lock mode automatically from configuration and tractor's control system.

The symbol below indicates the state of the axle lock mode. If symbol is visible, axle lock is enabled and active. If axle lock function hasn't been configured to the system, symbol is not visible at all.



4.5 Trailer drawbar control

Trailer drawbar can be controlled by activating the drawbar control enable switch or alternatively, xCrane system can detect the machine driving speed and activate the drawbar control automatically. Symbol below indicates, if the drawbar control is activated.



Drawbar control can be operated from left or right joystick X-axis or with separate thumbwheel. Crane controls can be disabled during drawbar controls. This is done with separate configure.

4.6 Trailer traction control

Trailer traction can be controlled from xCrane system. Traction is activated manually with direction switches connected to the system or it can be activated automatically based on the machine's driving direction and speed.

System has two types of traction controls: On-Off controlled and proportional controlled. ON-OFF control can be controlled from switches or with machines driving direction and speed. Proportional control can be operated with potentiometer or with machines driving direction and speed.

Symbol below indicates that trailer traction control is active.



4.6.1 Differential lock

Differential lock control is an extra feature with trailers that has traction with differential lock mechanism. Differential lock is controlled with switch and it engages/disengages only while the traction control is disabled. Symbol below tells that the differential lock is active.



4.6.2 Trailer brake

The trailer brake function is an extra feature to work alongside with the trailer traction. The brake can be activated with a switch or it can activate and deactivate automatically based on the machine's driving speed.

Following symbol will indicate the state of the trailer brake.



4.7 Winch control

Winch control can be activated with switch and can be controlled from thumbwheel.


If the symbol is gray, then the winch control is disabled and if it is blue then winch control is active.



4.8 Floating mode

It is possible to float the crane during trailer transportation in the xCrane application. This means that when the crane is mounted on the tractor, the boom can be safely placed on the trailer during transportation. The floating mode is activated normally by using an external switch, and the manufacturer can configure two activation sequences:

1. If xCrane is configured so that confirmation is not required from the display: press the activation button on the dashboard for at least 2 seconds, release it for 0.5–2 seconds and press it again for more than 0.3 seconds.
2. If xCrane is configured so that display activation is required: press the activation button on the dashboard once and then confirm the selection from the display.
3. Activate floating from the switch. Display confirmation not required.



This pop-up window will appear if the floating confirmation is enabled and floating is activated. Floating request can be rejected by pressing “X” button.

The floating mode is switched off by pressing the button again for more than 0.5 seconds.

The symbol below is visible when the floating mode has been activated.



Please contact your dealer to confirm which activation sequence is configured in your crane.

4.9 Radio control mode

The xCrane system can be used with variety of radio controllers.

The radio control is activated and deactivated from a switch. When deactivating the radio, the pop-up will appear to inform the user about the deactivation of the radio. The deactivation is done by pressing the "yes" button.



The following icons tell the state of the radio control.



The blue symbol indicates that the radio is operational and the radio signal strength is high. The yellow signal indicates that the radio signal strength is low. If the symbol is red, there is communication lost with the radio. When the radio control is disabled the symbol is gray.

While the radio control is enabled, the driver cannot be changed.

The radio control can be activated by a button on the display. The icon turns blue when the radio is activated. During this time the driver cannot be changed and the driver symbol is gray.



5 System sensors

5.1 Outside temperature

System can measure outside temperature and show it at the left side of the display.



5.2 Hydraulic oil temperature


System can measure the hydraulic oil temperature and show it at the left side of the display.



5.3 Hydraulic oil pressure sensors

If the hydraulic oil pressure sensor is connected to the system, it is shown on the display.

With the pressure sensor, the operator can see the operating pressure of the hydraulic system. This will help with the diagnostics.



5.4 Load pressure sensor

Load pressure sensor is usually mounted to the main boom cylinder. It can measure the pressure and indicate to the operator if the load is too high. Symbols below will indicate the status of the load pressure.



5.5 Hydraulic oil filter clogging indicator

Crane can be mounted with a hydraulic oil clogging indicator that indicates the clogged hydraulic oil filter. If the clogging indicator is active, the system show the symbol below.




5.6 Hydraulic oil level warning

There is possible to add a hydraulic oil level switch to the system. The symbol below indicates if the hydraulic oil level is too low.



If the hydraulic oil level is too low, it will trigger the fault and sets the following pop-up information.



If the operator resets the warning, it will pop-up again after 1 minute. Please contact your dealer about this feature.

6 Operator presence detections features

There are variety of operator presence detection features that can be configured to the xCrane system.

6.1 Seat switch mode

The xCrane control system includes a function for detecting whether the operator is seated in the cabin. The safety feature is optional.

If your crane is equipped with the seat switch function, the crane cannot be used if the operator is not in the operator's seat. The seat status can be observed from the display symbol. The symbol is green when all functions are working, and the operator is properly seated in the operator's seat. The symbol is orange when the seat is empty. If the symbol is red, there is an error in the sensor.



Please contact your dealer to confirm whether your crane includes this function.


6.2 Door switch mode

The xCrane control system includes a function for detecting whether the cabin door is properly closed. The door position can be observed from the display.



The safety feature is optional and it has 3 alternative configurations:

1. Door switch is disabled.
2. Door switch is enabled, allows operating when door is closed.
3. Door switch is enabled, allows operating after an operator acknowledges his/her presence in the cabin.



Please contact your dealer to confirm whether your crane includes this function.

6.3 Dead man switch safety mode

The xCrane control system includes a “Dead man” function. The feature is optional, and it can be activated with a following sequence from the button or switch.

- Press the button for predetermined time and the release
- Dead man mode is active for a predefined time
- Mode can be activated during that time again by pressing the button
- When there is 10 seconds left of the active time the operator icon starts to blink between green and orange



All the crane movements are disabled if mode is not active.

Please contact your dealer to confirm whether your crane includes this function.

6.4 Temporary presence detection mode

If one of the aforementioned presence detection modes is configured to the system, then it is possible to access temporary presence detection mode. This feature can be activated by pressing 2 seconds the defined push button or right joystick Z-axis control.

The temporary operator presence mode can also be activated from the display. The mode is activated by pressing X-button when the driver selection is highlighted and operator presence icon is orange. When this mode is active, the crane can be operated during the pre-defined time. Icon below indicates the state of the temporal operator presence mode. The green bar on the left side of the icon indicates the remaining pre-defined time.



Please contact your dealer about this feature.

7 Technion Quick trim

7.1 Introduction

The Technion Quick Trim feature enables the operator to quickly adjust the speed of the crane according to instant needs. Technion Quick Trim is designed for daily work. Different situations require different crane speeds.

The feature increases or decreases the speed of all functions simultaneously. Technion Quick Trim can be adjusted from the display or from the potentiometer mounted on the dashboard.

Please confirm your Quick Trim configuration from your dealer.

7.2 Speed setting process

The speed of the crane is adjusted through three parameters: Maximum Speed, Speed Balance and Technion Quick Trim.

When Technion Quick Trim is adjusted to 100% the crane moves according to the Max Speed settings. Speed Balance will not take effect at all. Adjust first the Maximum Speed while Technion Quick Trim is set to 100%

With lower Quick Trim values, the operator can adjust the balance between different movements. In order to adjust balance, the Quick Trim value can be decreased to 50%, for instance. The user will then be able to experience how the Speed Balance parameters will affect the system.

Once the Speed Balance parameters meet the requirements of the operator, the speed setting process of the Maximum Speed and Speed Balance parameters is complete. Technion Quick Trim can now be adjusted according to the current working mode.

7.3 Examples of Quick Trim

Technion Quick Trim/Speed balance system is simple and fast way to adjust your crane speed. In this chapter the use of this system is explained with three simple examples.

The basic formula of speed can be determined as shown below

$$\left(100 - \frac{(100 - \text{SpeedBalance}) * (100 - \text{QuickTrim})}{100}\right) * \frac{\text{MAXSpeed}}{100}$$

Example 1

Speed balance = 0%

Max speed = 100%

Quick trim = 50

$$\left(100 - \frac{(100 - 0) * (100 - 50)}{100}\right) * \frac{100}{100} = 50\%$$

The result is that the motion speed of a function is 50% of the max speed

Example 2

Speed balance = 100%

Max speed = 100%

Quick Trim = 50%

$$\left(100 - \frac{(100 - 100) * (100 - 50)}{100}\right) * \frac{100}{100} = 100\%$$

The result is that the Quick trim doesn't affect the selected motion speed at all.

Example 3

Speed balance = 25%

Max speed = 80%

Quick trim = 50%

$$\left(100 - \frac{(100 - 25) * (100 - 50)}{100}\right) * \frac{80}{100} = 50\%$$


The result is that the motion speed of a function is 50% of the max speed.

8 Settings menu

8.1 Menu structure


Settings - Crane	Settings - Joystick	Settings - Diagnostics	Settings - System
<ul style="list-style-type: none"> • Max speed • Min speed • Acceleration ramps • Deceleration ramps • Speed balance • Rotator direction • Progression control • Slew speed • xCrane PLUS • xCrane PRO 	<ul style="list-style-type: none"> • Calibration • Dead band • Filter 	<ul style="list-style-type: none"> • Output • Joysticks • Sensors • Input • System • Software info • Fault log • Boom position 	<ul style="list-style-type: none"> • Display settings • Copy parameters • Factory reset

8.2 Settings - Crane




In the Settings menu, the Crane submenu can be found under the boom symbol which is highlighted in the image above.



If the xCrane PLUS mode is activated from the main view mode selection, the operator can toggle menus between the normal xCrane and xCrane PLUS by pressing the boom symbol button.



If the xCrane PRO mode is activated from the main view mode selection, the operator can toggle menus between the normal xCrane and xCrane PRO by pressing the boom symbol button.



8.2.1 Max speed





The speed of each movement from maximum speed. The Max speed value is a percentage ratio of the total speed range. Both directions of each movement can be adjusted separately.

Use the “next page” and “previous page” buttons to scroll between auxiliary valve and crane valve settings.

Before you adjust the maximum current, set the Quick Trim value to 100%. Otherwise it will limit the speed of your setting.

8.2.2 Min speed















Minimum current for the solenoid. Should be set according to following process:

1. Increase the value that crane function barely starts to move
2. Decrease the value back until the moving ends
3. Decrease 2 steps more (=10mA) from the limit that moving ended
4. Perform this for each function and for each direction

Use the “next” and “previous” buttons to scroll between auxiliary valve and crane valve settings.

8.2.3 Acceleration ramps







Crane		Acceleration ramp(ms)		
	250 250	250 295		Test
	250 250	250 250		
	250 225	250 250		







Crane		Acceleration ramp(ms)		
	VALVE 7 250 250	250 250	VALVE 8 	Test
	BUS VALVE 1 0 0	0 0	BUS VALVE 2 	
	BUS VALVE 3 0 0	0 0	BUS VALVE 4 	

The acceleration ramps define how quickly control values go from min speed to max speed. The bigger the ramp value, the longer it will take for a control value to go from min speed to max speed. Set the acceleration ramps so that crane movements are smooth but without long delays in control.

Use the “next” and “previous” buttons to scroll between auxiliary valve and crane valve settings.

8.2.4 Deceleration ramps



Crane		Deceleration ramp(ms)		
	250 250	250 250		Test
	250 250	250 250		
	250 250	250 250		

Crane		Deceleration ramp(ms)		
	VALVE 7 250 250	250 250	VALVE 8 	Test
	BUS VALVE 1 0 0	0 0	BUS VALVE 2 	
	BUS VALVE 3 0 0	0 0	BUS VALVE 4 	

The deceleration ramps define how quickly control values go from max speed to min speed. The bigger the ramp value, the longer it will take for a control value to go from max speed to min speed. Set the deceleration ramps so that crane movements are smooth but without long delays in control.

Use the “next” and “previous” buttons to scroll between auxiliary valve and crane valve settings.


8.2.5 Speed balance



With the Speed balance settings, you can define the relative speed between each crane function when adjusting the crane speed by using Technion Quick Trim in the Working view. In this example, the operator wants the grapple functions to be as fast as possible in all situations.



Use the “next” and “previous” buttons to scroll between auxiliary valve and crane valve settings.

8.2.6 Rotator direction




It is possible to change the rotation direction of the rotator. The change is made by pressing the button. Arrow shows the direction of the rotator.

8.2.7 Progression control



With progression control, the operator can change the linearity of the control signal.





- 1 Movement speed (vertical axle)**
- 0 % - No movement
 - 100 % - The maximum speed

- 2 Joystick position (horizontal axle)**
- 0 % - Center position
 - 100 % - Extreme position


- 3 Progression value**
- 0 % - No progression
 - 100 % - The maximum progression

If the value is 0%, the control signal is the same as the position of the joystick. By increasing the value, the operator can improve precision at the beginning of the joystick movement. Use the arrows to scroll between auxiliary valve and crane valve settings.

8.2.8 Slew speed



8.2.9 xCrane PLUS




xCrane PLUS control is a control mode where the system drives multiple crane movements at the same time. This feature allows the crane to move like parallel boom, without the parallel bar.




This feature can be only used with normal crane boom, not with the parallel boom.

For the crane movements, operator gives a speed percent value for each cylinder direction. With these values the operator can set the control ratio between boom cylinder movements to reach the best possible parallel movement.

Icons at the top of the adjusting page are showing the direction of the parallel movement.



Values are changed from the display. Activate the movement and increase/decrease the value with +/- buttons. Value multiplier can be changed from the middle button (with x2). There are three multiplier values, x1, x2 and x10.



Operation mode parameters are changed by pressing the buttons next to the parameter name.

The PLUS control option is selected from the main view mode selection. There are three options that changes the behavior of the crane:

- Parallel boom movement with manual controlled extension
- Parallel boom movement with automatic extension control
- Extension/Lift movement with manual outer boom control

Extension/Lifter mode is available if the system is configured with automatic extension mode. Extension direction can be changed if "Automatic extension mode" is activated.

8.2.9.1 Parallel boom




The parallel boom mode is the default mode.


With the parallel boom mode, the operator controls two movements at the same time; Lift and outer boom. Booms are controlled with the outer boom joystick (usually left Y-axis).

Adjusting the values changes the boom behavior. Lift control from right joystick Y-axis is added to the lift boom control and with this feature, the angle of the parallel movement can be corrected.

This mode works best with the cranes mounted with a harvester head.




8.2.9.2 Parallel mode with automatic extension



In the parallel boom mode with the automatic extension, the operator controls three movements at the same time. Control is basically same as the previous, but with the extension control added.

Extension cylinder is also provided with speed value for both directions.




The PLUS mode doesn't have any real time sensors and it cannot calculate the boom position. The cylinders are driven with the defined speeds, and if the any of the cylinders reaches the fully in / out position, the xCrane system doesn't know that.


In the PLUS mode, it is possible to use on/off sensors to indicate for the system that cylinder end is reached. This prevents the unnecessary power loss.

With the automatic extension mode, at least the extension cylinder in sensor is highly recommended.

8.2.9.3 Extension/Lifter mode



With this mode, the operator controls the lift boom and extension boom at the same time. Outer boom is controlled manually.




Extension/Lifter boom control mode is available if the automatic extension control is enabled.

With this control mode, the extension is controlled from the same joystick as lift boom. Operator gives a speed value for both cylinder directions for lift and extension. It is possible to affect the automatic extension control by using the extension control from the joystick.

This mode is useful when loading/unloading.


8.2.10 xCrane PRO

If the system has the xCrane PRO license, then two control modes, PRO and PLUS, become available. The mode can be changed by pressing the mode selection button at the top right corner of the screen.




With the xCrane PRO mode (1) the driver controls the movement of the tip instead of individual cylinders.

The xCrane PRO control mode have three possible preset parameter groups. Each preset group includes set of parameters that can be changed from the adjust menu. Number of preset groups can be configured with the manufacturer configuration.



Preset control mode is selected by pressing the button with the name of desired preset mode.

The menu button will open the settings of the currently activated preset mode. The driver can adjust the movement speeds of the crane.




X speed limit: horizontal movement speed limit of the tip.

Y speed limit: vertical movement speed limit of the tip.


Extension speed limit: speed limit for retracting and extending the extension boom.

Slew speed limit: While slewing the tip moves at the same speed regardless of the distance of the tip from the boom base. If slew speed limit is set 0.0, then the speed is not limited.


8.3 Adjusting setting values



To select the function, you would like to adjust, activate the desired function by using the joystick. The icon of the selected function will turn blue and next to the opposite joystick appears – and + symbols. Use the z-axis of the opposite joystick to increase or decrease the value. Once you have set the correct value, you can return to the submenu or start adjusting another function.




In the example above, the operator has selected the Outer boom in function by using the left joystick. The operator is now able to adjust the max speed for that function by using the z-axis of the right-hand joystick.





It is also possible to adjust values via the display. Activate then movement and direction by pressing the icon, then press the blue “up” or “down” arrows

to adjust the value. Exit from the selected movement adjust by pressing “return” button or pressing the icon.




The operator can test adjusted values by pressing “Test” button in the adjust mode. Test mode sets the crane to the normal operation mode, all crane movements are available. Press the button to exit the test mode and return to the adjust mode.

To go back to the Settings menu, press the “Return” button.



Joystick parameter adjusting is basically the same as the valve parameter adjusting. First choose channel to adjust and change value from the opposite side joystick Z-axis.




It is also possible to adjust joystick parameter values via display. Axis is selected by pressing the joystick icon. Each press changes the channel. Value is changed by pressing the blue “up” or “down” buttons. Exit the active channel adjust by pressing the joystick icon or by pressing the return button.

8.4 Data saving


Data saving needs to be done if any of the crane or joystick values are changed.

After all the necessary adjustments has been done and user wants to return to working view, press the return button. If there are any changes at the parameters, then user is asked to save the values.



User can save the parameters by pressing OK (green button) or discard made changes by pressing the “Deny” (red button). After the saving (or discarding) screen goes back to working view.


8.5 Settings - Joystick




In the Settings menu, the Joystick submenu can be found under the Joystick icon.

8.5.1 Calibration

The calibration of the joysticks involves three steps.



Leave the joysticks in the center position and press “Next”. Green dot next to the joystick value indicates that the current channel is OK.



Move both joysticks so that all joystick directions reach the full stroke position. Do not forget the Z-axis movement. When all movements have reached the full stroke position, press Enter. If nothing happens when pressing Enter, one of the movements has not reached the end position.

Please repeat the step and make sure that all the functions for both joysticks have been covered.

Joystick	Calibration			
X	49 %	●	●	50 % X
Y	48 %	●	●	49 % Y
Z	50 %	●	●	50 % Z
A1				A1
A2				A2

Move edge to edge and press next

Step: 2/3

Green dot next to the joystick value indicates that the current channel is OK. If “A1” or “A2” from either side is showing values, then it means that there is auxiliary joystick configured to the system, and that needs to be calibrated just like other channels

Joystick	Calibration			
X	49 %	●	●	50 % X
Y	48 %	●	●	49 % Y
Z	50 %	●	●	50 % Z
A1				A1
A2				A2

Calibration done! Press ENTER

The calibration has been completed. Press “Enter” to confirm your calibration data. Save your data by returning to the working view.


8.5.2 Dead band

Joystick	Dead band (%)			
X	12	5	X	
Y	5	10	Y	
Z	11	6	Z	
A1	17	17	A1	
A2	17	17	A2	

Test


The Dead band settings define how much the joystick has to move from the center point to activate a movement. This is used to prevent unwanted movements, for example while driving.

8.5.3 Filter




This function filters small vibration in the joysticks that occurs when machine is shaking in the working environment. It also filters too fast moves generated by operator. The bigger the value is, the more the incoming joystick signal is filtered.

8.6 Settings - Diagnostic




In the Settings menu, the Diagnostic submenu can be found under the magnifying glass symbol. Diagnostic gives a user to possibility to check different parts of xCrane system.

8.6.1 Output



This screen displays control signals to the valve. Use the arrows to scroll between auxiliary valve and crane valve settings.

8.6.2 Joysticks



This screen displays incoming joystick signals. Signal are percentage values of the measured joystick signal. Values should be around 50% when the joystick is centered.

Value of the channels should be as mentioned bellow to meet the xCrane system requirements.

Correct values for joystick directions:

- Right joystick X-Axis to left =~ 90% and to right =~10%
- Right joystick Y-Axis to up =~ 10% and to down =~ 90%
- Right joystick Z-Axis to up =~ 10% and down =~90%
- Left joystick X-Axis to left =~ 10% and to right =~ 90%
- Left joystick Y-Axis to up =~ 90% and to down =~10%
- Left joystick Z-Axis to up =~ 10% and down =~90%

If these values are not met, then there is wrong joystick configuration, or the wiring of the joystick doesn't meet with the requirements. In that case please contact your dealer.

It is vital for the software that the joystick channel directions are correct.

8.6.3 Sensors

Diagnostics	Sensor	
Outside temperature	0	
Oil temperature	2785 mV	
Oil pressure	2792 mV	
Load pressure	1730 mV	
Speed potentiometer	0 mV	
Traction potentiometer	1023	
Oil filter pressure switch	N/A	

This screen displays the diagnostic measurements provided by optional external sensors. Unit after the signal value depends on the sensor configuration. Unit can be voltage (mV), ampere(mA) or resistive(Ω). If the sensor is not configured to your system, the signal value is zero (0) and no unit is shown. Potentiometers are always measured by voltage hence the mV unit after the value.

Diagnostics	Sensor	
Seat switch state	ON	
Door switch state	OFF	
Dead man switch state	N/A	
Boom home sensor	N/A	
Stabilizer home sensor	N/A	

Diagnostics	Sensor	IN	OUT
Lift ON-OFF sensors	N/A	N/A	N/A
Tilt ON-OFF sensors	N/A	N/A	N/A
Extension ON-OFF sensors	N/A	N/A	N/A

This screen shows states provided by external (on-off) sensors. States of the switches/sensors are: ON, OFF, ERROR and N/A.

8.6.4 Inputs

Diagnostics	Input	
Function:	State:	
Left stabilizer up	0	1 / 2
Left stabilizer down	0	
Right stabilizer up	1	
Right stabilizer down	0	
Steering enable	0	
Crane/stabilizer selection	0	
Floating valves	0	

The diagnostic pages display the status of system inputs. The state of the input changes from 0 to 1 if the button or switch is working properly.

Use the arrows to scroll between pages.

8.6.5 System

Diagnostics	System	
System voltage:	24335 mV	
Total working time:	9 h 52 min	
Current working time:	0 h 1 min	
Total power on time:	124 h 10 min	
Last boot power time:	103 h 27 min	
Current boot time:	20 h 43 min	


Diagnostics	System	
Machine CAN bus state:	Connected	
Machine CAN BUS:	ISOBUS	

The Supply Voltage and Power ON Time are visible in the system diagnostics menu. The Power ON Time is the cumulative number of hours the xCrane power supply has been switched on.

Other time variables on the system diagnostic page has been calculated from the total working time. These time variables can be helpful in fault and other diagnostic.


The operator can see the status of the connected machine bus by pressing the arrow button.

8.6.6 Software info




This screen displays information about the software of the system modules (TEC152, display, possible external joystick and/or steering module).

8.6.7 Fault log





The Fault log displays all warnings and alarms. This information is only intended for the manufacturer.

Use “Arrows” to scroll through the fault log.




Fault log page, if there are no fault in the system.

8.6.8 Boom position




8.7 Settings - System




In the Settings menu, the System submenu can be found under the gear symbol.

8.7.1 Display settings





The language, time, date and display brightness can be set here.

Language can be changed from language menu. Menu is opened by pressing the button where with the current language.




Time can be changed by pressing the time value buttons. The format of the time is "hh:mm".


Date can be changed by pressing the date value buttons. The format of the time is “yyyy:mm:dd”.



Brightness is adjusted by slider that will appear when the button has been pressed. Brightness is set from the slider.





8.7.2 Copy parameters




Operator settings can be copied here. Select the operator from whom you would like to copy the settings to the active operator.

User can change the operator whom to copy the parameters by clicking the button.



Parameters are copied from selected driver to current by pressing the OK button. After this follows the pop-up.

8.7.3 Factory reset




All parameters can be reset to factory values. This should not be done unless all parameters are badly wrong for some reason. The factory reset only resets the parameters of the current operator.


9 USB settings

USB settings are always allowed when USB stick is connected. If USB stick has been ejected, then it needs to be removed and then connect again.

9.1 Read information



In the Read information menu, the user can save configurations, parameters and fault logs to the USB stick.



If the any of the files below is already on the USB drive, then the display asks if the user wants to overwrite the existing file. Info also shows the corresponding file name. The "XCCONF.DAT" is shown as an example.

9.1.1 Backup

The Backup option creates an "XCBACKUP.DAT" file and saves it to the USB stick. The file contains configurations and parameters from all drivers.

9.1.2 Configure

The Configure option creates an "XCCONF.DAT" file and saves it to the USB stick. The file contains system configurations.

9.1.3 Default driver

The Default driver option creates an "XCDEF.DAT" file and saves it to the USB stick. The file contains the default parameters (the factory reset parameters).


9.1.4 Logs

The Logs option uploads the fault log to the USB stick. The file is for the manufacturer only.


9.1.5 Current driver

The Current driver option creates an "XCCURR.DAT" file and saves it to the USB stick. The file contains parameter values from the currently active driver.

9.2 Write information



In the Write information menu, the user can load configurations and parameters from the USB stick to the system.



In Write information menu each button is invisible if function related file is missing from the USB stick. For example, if user wants to download factory settings and doesn't have "XCDEF.DAT" at the USB stick, the "Default driver" button is not visible.

9.2.1 Restore

This option is used to restore data to the system. The "XCBACKUP.DAT" file is needed to restore data. This feature can be used to transfer configurations and parameters to other xCrane systems.

9.2.2 Configure

The Configure option restores configurations from the "XCCONF.DAT" file.

9.2.3 Default driver


The Default driver option restores the default parameters from the "XCDEF.DAT" file.

9.2.4 Current driver


The Current driver option restores the parameters from the “XCCURR.DAT” file to the currently selected driver.

9.3 File transfer information

If any of the Read or Write information options is selected and the USB stick contains the correct file, the system starts to scan the USB stick.



When the process of the write information has been successfully completed, the following screen appears.



When the process of the read information has been successfully done, the following screen appears.



After operations it is recommended to press “Eject USB button before removing the USB stick. By doing that the user can avoid data corruption with the configure, parameter and log files.

After pressing the “Eject USB” button, screen goes to back to working view.

9.3.1 File operation errors

There are different kinds of errors that can occur during USB operations. If an error occurs, a message is shown on the display. A list of all error messages can be found below.

Error message	Description
File not found!	Correct file is missing from USB stick
Communication error!	Connection to USB has been lost
File write error!	Error in writing to USB
File read error!	Error in reading from USB
File verify error!	System can't verify file in USB
Zip creation error!	System error in creating the file
Zip extract error!	System error in extracting the file
Zip CRC error!	Checksum error in file
Zip mount error	Wrong file format or file not found on USB stick
Writing is not allowed!	USB stick is write protected
Error!	Any other reason that is not mentioned above

Index

Acceleration ramps	59
Adjusting setting values	68
Axle lock	28
Backup.	85
Boom position	79
Calibration	72
Configure.	85
Configure.	87
Copy parameters	81
Crane control mode	21
Current driver	86
Current driver	88
Data saving	71
Dead band	73
Dead man switch safety mode.	47
Deceleration ramps	59
Default driver.	85
Default driver.	87
Differential lock.	30
Display settings	80
Door switch mode	46
Driver selection	20
Examples of Quick Trim.	53
Extension/Lifter mode.	65
Factory reset	82
Fault log.	78
File operation errors	90
File transfer information	89
Filter	74
Floating mode	32
General speed	21
General warnings.	8
Hydraulic oil filter clogging indicator.	40
Hydraulic oil level warning.	41
Hydraulic oil pressure sensors.	38
Hydraulic oil temperature	37
Inputs	77
Introduction	50
Joysticks	75
Load pressure sensor	39
Logs.	86
Main page buttons	20
Max speed	58
Menu structure.	56



Menu	22
Min speed	58
Navigation.	13
Operating modes	23
Operator presence detections features	43
Output	75
Outside temperature	36
Parallel boom	64
Parallel mode with automatic extension	64
Pop-up information	19
Progression control	61
Radio control mode	33
Read information	85
Restore	87
Rotator direction	60
Seat switch mode	45
Sensors	76
Settings - Crane	57
Settings - Diagnostic	75
Settings - Joystick	72
Settings - System	80
Settings menu	55
Slew speed	62
Software info.	78
Speed balance	60
Speed setting process	51
Stabilizer control	26
Steering by joysticks mode	27
Suspend mode	25
Symbol definitions	15
System architecture	11
System safety	7
System sensors	35
System	77
Technion Quick trim	49
Temporary presence detection mode	48
Trailer brake	30
Trailer drawbar control	29
Trailer traction control	30
USB settings	22
USB settings	83
Winch control	31
Working view	14
Write information	87
xCrane PLUS	62
xCrane PRO	66

